


On-board mini monitor - user manual



Legend:

- description of the function
- short press button
- long press button

Warning !

- Always operate the touch screen with your finger or a special pen with a tip made of plastic
- Do not touch the screen with sharp metal objects, it may cause scratches and damage the touch panel
- As a result of the long life operation, battery loses its nominal capacity, so from time to time should be corrected and programmed in the device setup
- Batteries should not be fully discharged, it can cause permanent damage
- Over-discharge results in the loss of batteries capacity
- Do not use charging mode R1 "recondition" with the gel, AGM and lithium batteries